

Vehicle & service details

Mercedes-Benz GLC300 e 4MATIC X253

2.0 litre · 235 kW | Nov 2019 onward | SUV | Plug-in hybrid

Vehicle REGO

VIN (17 characters)

Service date

Odometer (km)

Service type / A or B

Capacities & specifications

Engine oil capacity

7 L / 6.5 L

7 L · Without 4MATIC · Oil change with filter

6.5 L · With 4MATIC · Oil change with filter

Coolant capacity

16 L

Engine cooling system

Service refill

7.5 L · Low-temperature cooling circuit · Service refill

Engine oil specification

MB 229.5

Coolant specification

MB 325.6 or MB 326.6

MB 325.6: concentrate, dilute before use

MB 326.6: premixed, do not add water

Check levels after filling. Coolant capacity is the system volume, not a top-up amount. Let the cooling system cool before opening the reservoir.

Products used

Engine oil brand / product

Viscosity

Oil added (L)

Coolant brand / product

Mix / concentration

Coolant added (L)

Record the amount actually used above. Keep product labels and receipts with this record.

Work / findings / follow-up

Parts / part numbers / receipts

Completed by

Next service date

Next service (km)

Service checklist

Mercedes-Benz GLC300 e 4MATIC X253 | 2.0 litre · 235 kW

Service A and Service B alternate, normally once a year. Follow the time or kilometres remaining on your dashboard, whichever comes first. Extra work can fall due with either service.

Service A

When Service A is due on the dashboard

Replace

- ☐ Replace the engine oil and oil filter.

Check & maintain

- ☐ Check brake operation, pads and discs.
- ☐ Check tyre condition and pressures, including the spare if fitted.
- ☐ Check coolant, brake-fluid and washer-fluid levels.
- ☐ Check the lights, horn, wipers and washers.
- ☐ Check the bonnet catch and door hinges.

Service B

When Service B is due on the dashboard

Replace

- ☐ Replace the engine oil and oil filter.

Check & maintain

- ☐ Check brake operation, pads and discs.
- ☐ Check tyre condition and pressures, including the spare if fitted.
- ☐ Check coolant, brake-fluid and washer-fluid levels.
- ☐ Check the lights, horn, wipers and washers.
- ☐ Check the bonnet catch and door hinges.
- ☐ Check steering, suspension and driveshafts for wear or damage.
- ☐ Check the engine compartment and underside for leaks or damage.
- ☐ Check the auxiliary drive belt for wear.
- ☐ Check seat belts and buckles for damage and proper operation.
- ☐ Check the headlamp aim and levelling, if fitted.

Maintenance reference

Mercedes-Benz GLC300 e 4MATIC X253 | 2.0 litre · 235 kW

When to change each item

Item	When to change / inspect
Engine oil and oil filter	At each Service A and Service B
Engine air filter	More than 80,000 km (50,000 mi) or 4 years since last change
Spark plugs	More than 75,000 km (46,500 mi) or 3 years since last change
Brake pads and discs	Inspect at each service; replace when worn Brake pads do not have a fixed kilometre replacement interval.
Wiper blades	Inspect at each service; replace as needed
Tyres	Inspect at each service; replace as needed

For jobs with both a time and a kilometre limit, use whichever comes first.

Service history

Date	Odometer (km)	Work completed / next item due